


DiMarzio, Inc.

1388 Richmond Terrace, PO Box 100387, Staten Island, NY 10310, Tel(718)981-9286, Fax(718)720-5296

Bluesbucker in neck position

Standard HB in bridge position



Install Bluesbucker with adjustable polepieces towards bridge. Install bridge pickup with cable exit away from controls.

Note: Tailpiece should be connected to common ground. All grounds \perp must be connected.

Copyright (C) 2003 DiMarzio, Inc. All rights reserved